



**ISTRUZIONI DI MONTAGGIO
PROTEZIONI CARTER
CM021 SX**

**INSTRUCTION FOR ASSEMBLY
CRANKCASE PROTECTORS
CM021 SX**



Via Lavino 209/C - 40050 Monte San Pietro (BO) - Italy
Ph. +39.051.67.62.200 - Fax +39.051.67.62.202
www-for-racing.com
info@for-racing.com

WWW.FOR-RACING.COM



Dopo aver rimosso le viti originali, applicate il copricarter facendo attenzione a montare sotto di esso gli spessori di $\varnothing 12 \times \varnothing 6 \times \neq 1$ nei punti indicati.

Avvitare le viti di svasate di M6 x 50

Verificare il serraggio delle viti per un corretto funzionamento

 ATTENZIONE

Tutti i prodotti For Racing sono realizzati per uso esclusivamente agonistico ed in circuito chiuso, vietato l'uso su strade pubbliche.



After removing the original screws, apply crankcase protector taking notice to fit under it the thicknesses of $\varnothing 12 \times \varnothing 6 \times \neq 1$ at the points indicated.

Tighten the countersunk screws M6 x 50

Check the tightening of the screws for proper operation

 ATTENTION

All For Racing parts are intended for exclusive racing use on closed tracks. Their use on public highways and roads may be forbidden